



# Didosi Tileable Tray

## Installation Guide

Watch the videos and checkout the drawings on the web page below before you start your install

<https://www.henrybrooks.co.nz/tileable-shower-tray/>

- Ensure your floor is level and perpendicular to your walls
- Fit a newly installed EasyClean trap in floor @ center of tray
- Use a Construction Adhesive or Silicone to fix tray to your floor ensuring the tray is level and square to the walls
- Fit and silicone the top of your waste through the tray
- Position and fix the supplied Waste Grate Frame ensuring a blob of silicone is applied under the 4 corners of the Grate Frame (to allow for water to run under the grate frame)
- You are now ready to waterproof the walls before you lay the floor tiles refer to the video where needed
- Recommended Tile Adhesive is PRO-FLEX 50FC as shown below (supplied with Tray) Is a one component no primer required, fast cure high performance construction thixotropic moisture curing Polyurethane adhesive with high mechanical strength. Specifically tested for this product.
- Apply Pro-Flex adhesive to tray (Requires No Primer) using provided spreader, we recommend you do not fill the tray grooves.
- We strongly recommend you use an epoxy grout when grouting

