



Thankyou for your order

Ph. 09 913 3110 Fax. 09 913 3113
5 Smales Rd, East Tamaki, Manukau
P.O.Box 58031 Greenmount, Manukau 2141



AUCKLAND // WELLINGTON // CHRISTCHURCH

Things to think about before you commence with your shower lining installation

For complete and correct installation of your new Acrylic Shower wall lining we recommend you confirm that.

Additional framework has been installed (ie, in red) to give support to the lining and wooden fixing for the shower door installation. That a wall lining (ie, Gib Aqualine) has been installed over the framework. Please note the gib board is not to be sealed or painted in any manner as this will prevent the curing of the wallboard adhesive. We recommend **Sika Showerbond**.

The finished installation showing the relative position of the frame, shower tray, wall lining (Gib Aqualine) and the acrylic shower lining.



ACRYLIC WALL LININGS INSTALLATION INSTRUCTIONS

- 1) Please ensure the shower tray has been installed square and level and has been plumbed correctly in accordance with the manufacturer's instructions.
- 2) Check the wall linings for freight and handling damage and report any damage immediately to the source of supply.
- 3) Lift the lining into position to determine the location of the moulded wall caddy,(if it has one), Once established lift off and proceed to the next step.
NOTE; If the tray has not been installed level or the walls are out of plumb, scribe and cut the bottom edges of the linings so they will sit flat on the tray and hard onto both wall surfaces.
- 4) Measure, mark and measure again the location of the shower rose and mixer. Transfer these measurements carefully onto the acrylic lining, and double check your measurements before you cut the holes in the lining.




NOTE: Cutting of the acrylic should be undertaken with a hacksaw or jig saw with a minimum of 18 teeth per inch. If you have to remove a considerable length of liner, you can use a stanley knife with a straight edge to cut/mark the liner at the correct place and bend it at the cut/mark to break the excess off at that point. Redress the cut edge with sandpaper. For drilling of holes up to 12 mm, use a standard twist drill applying average pressure. For drilling holes larger than 12 mm, use a hole saw.

5) Ensure that the surfaces to be glued are free from dirt, dust and grease. Remove the clear protective covering from the shower tray upstand only, so that the silicone contacts directly with the surface of the acrylic tray and not merely onto the protective covering.



6) Apply a continuous bead of silicone (Approx 8mm diameter) along the entire length of the shower tray upstand. Pay particular attention to the front corners of the tray ensuring that plenty of silicone is applied over the last 50mm as shown to the right.



7) Now working quickly, apply a 6mm bead of Sika Showerbond adhesive in vertical lines approx 80mm apart onto the gib board surface. Applying the adhesive in this manner will reduce the likelihood of any air bubbles from being trapped upon fitting the liner.

8) Lift the wall lining into position over the mixer and shower rose fittings and press firmly into position.

9) Using a large cloth or rag, rub all over the liner firmly to spread and flatten the beads of adhesive between the gib board and liner, allow 24 hours for adhesive to cure.

10) Clean up any excess silicone sealant with white spirits or mineral turps.

NOTE; No silicone should be visible or used on the inside of the shower enclosure.

11) Complete the installation by fitting the mixer and shower rose.

12) Door and screen installation can now proceed according to the installation instructions

